

Saf-T Vent CI Tall Cone Flashing With Rain Cap Installation Instructions

Directly On Flat Roof. Prepare a square or round opening per the framing chart. Apply weather-stripping or outdoor caulk to the bottom of the cone plate. Attach the cone to the roof using common construction methods. Flash over the cone plate and seal the fastener heads using normal roofing requirements. When the vent pipe is in place through the Tall Cone, attach the Tall Cone storm collar around the pipe. Apply RTV sealant around the top of the storm collar and the pipe. Install the Rain Cap on the last section of vent per the Rain Cap installation instructions.

